

MaxxShade Tension Adjustment Guide



1



Locate the end of the blind with the metal pin and remove the 3 screws which hold the plastic retaining strip.

2



Remove the plastic retaining strip.

3



CAUTION! The roller blind is spring loaded. Carefully remove the metal end of the blind from its recess.

4



Holding the blind in place, wind the metal bar clockwise until tension builds up (approx. 4-5 turns).

5



Carefully place the end of the blind back into the recess. Be careful not to release the blind as this will cause the tension to slide.

6



Replace the plastic retaining strip and secure with the 3 screws.